



Corporate Hazard Identification & Risk Control

HIRA #
15.60

Quick-Cut Saw Use

Applicable Zones:	Project	X	Yard	X	Office		Asphalt Plant	
--------------------------	---------	--------------	------	--------------	--------	--	---------------	--

HAZARD(S)

- Accidental Contact with another Worker (P)
- Equipment Hazards (P)
- Exposure to Exhaust Fumes (P)
- Lacerations (P)
- Musculoskeletal Disorders from Kickback (P)
- Property Damage (P)

PRE-CONTROL RISK

Likelihood 3	Consequence 5	Pre-Control Risk 15
-----------------	------------------	--------------------------------

CONTROLS

Elimination	Pre-use inspection required. Tag and remove and defective saw or blade from use immediately
Substitution	
Engineering	All connections made must be tested for leaks.
Administrative	Consult SDS before handling for proper PPE and safe handling procedures. Keep cutting area clear of tripping hazards.
PPE	High Visibility Clothing, Hard Hat & Safety Boots at a minimum must be worn at all times. Specialized PPE may be required depending on the task. (ie safety glasses)

POST CONTROL RISK

Likelihood 1	Consequence 5	Post-Control Risk 5	Risk Reduction 10	Critical or Not Critical No
-----------------	------------------	--------------------------------	----------------------	-----------------------------------

LEGISLATIVE REFERENCES

O.Reg 213/91: S. 109
O.Reg 213/91: S. 112
O.Reg 851: S. 39

OTHER STANDARDS & REFERENCES

J-AAR Manual: P1.4.7
J-AAR Manual: P1.5.4.7